GARMENT INSTRUCTION INSERT

Not SENT 03/19/24

NOTES:

- •DOUBLE SIDED PRINTED INSERT CARD STOCK
- •DO PRINT BLUE. BLUE=GUIDE. GUIDE IS ON SEPARATE LAYER
- •ART IS TO SCALE
- •BOOKLET DIMENSIONS: 4inch X 6inch

USER MANUAL

RECHARGEABLE COOLING CIRCULATORY VEST


INCLUDED POWER BANK 5V 10000mAh and charging kit.

SPECIFICATIONS

- COOLING VEST: 100% POLYESTER
- COLOR: NAVY
- SIDE ADJUSTABLE DEVICE: STRETCH VELCRO
- WATER CIRCULATION UNIT: OUTER SHELL 100% POLYESTER LINING; 100% NYLON
- BLADDER & TUBING: SILICONE
- REFILLABLE ICE PACK: PET PLASTIC

COOLING TIME

- 1-3 HOURS FOR 450ML (15OZ) FROZEN ICE PACK
- OPERATION AMBIENT: 10°C-65°C (50°F-149°F)



INSTRUCTIONS

1. Turn the lid on backside counter clockwise.



2. Fill ice pack with 450 ml (15oz) of water and freeze.



3. Fill vest with 500 ml (17oz) of cold water.



4. Connect full charged battery with USB.



5. Place battery into battery pocket.



6. Press & hold power button for 3 seconds unit power button light blue.





FRONT OF INSTRUCTION INSERT BACK OF INSTRUCTION INSERT

GARMENT INSTRUCTION INSERT Not SENT 03/19/24

NOTES:

- DOUBLE SIDED PRINTED INSERT CARD STOCK
- •DO PRINT BLUE. BLUE=GUIDE. GUIDE IS ON SEPARATE LAYER
- •ART IS TO SCALE
- •BOOKLET DIMENSIONS: 4inch X 6inch

USER MANUAL

RECHARGEABLE COOLING CIRCULATORY VEST

INCLUDED POWER BANK 5V 10000mAh and charging kit.

NOTES BEFORE USE

- 1. Read all garment & battery instructions and warnings before use.
- 2. Before use check compatibility between your garment and Power Bank. Be certain to use your Avignon product with the provided Power Bank or with a power bank that has no more than a (2.1) Amp output.

INSTRUCTIONS

- 1. Turn the lid on backside counterclockwise.
- 2. Fill ice pack with 450 ml (15oz) of water and freeze.
- 3. Fill vest with 500 ml (17oz) of cold water.
- 4. Connect full charged battery with USB.
- 5. Place battery into battery pocket.
- 6. Press and hold power button for 3 seconds unit power button light blue.

CARE

- 1. Read all instructions before using Avignon products.
- 2. Switch off and remove moisture, prefer to clean by hand then hang dry.
- 3. Use mild soap or detergent only. Do not use bleach.
- 4. Do not put in dryer. Do not iron. Do not wring to dry. Do not dry clean.















USAGE

- 1. Be certain to use your Avignon product with the provided Power Bank or with a power bank that has no more than a (2.1) Amp output. Be certain that you do not use a battery powered garment with an Amp rating higher than the maximum capacity output rating of the power bank used to power the battery powered garment. Failure to do so can overheat the battery causing damage.
- 2. Recommended power setting of 50% is sufficient for temperatures around 10°C-18°C (50°F- 64°F) while at lower temperature setting the power to 75% or 100% is sufficient. It is not recommended to use the 100% power setting for a long time as it may cause overheating and/or bodily discomfort.

WARNINGS

- 1. Read all instructions and warnings before use.
- 2. Before use check compatibility between your garment and Power Bank.
- 3. Use carefully. Do not use while sleeping or unconscious.
- 4. In the rare event of experiencing any sensation of discomfort while using any Avignon product, immediately remove the garment and unplug any wires and Power Banks.
- 5. Do not attempt to disassemble or alter any part of this product or Power
- 6. Do not store Power Bank below -4°F (-20°C) or above 120°F (49°C).
- 7. Do not allow Power Bank to come into contact with water or other liquids. If water or other liquids enter the power bank's interior immediately unplug the product from the Power Bank.
- 8. Continued use of a potentially damaged product may result in fire or an electrical shock.
- 9. Make sure to turn the battery powered garment off and disconnect from Power Bank when not being worn.
- 10. Recycle all Power Banks and batteries in accordance with local regulations.

STORAGE

- 1. It is important to maintain at least 25% of your battery power when not in use. Failure to do this will result in performance problems and reduced battery
- 2. Disconnect the Power Bank from the garment when not in use because even when it is turned off, the garment will continue to slowly drain power from the
- 3. Our Power Bank is very similar to a typical cell phone battery, so be sure to treat the battery with care. Proper care and storage of the battery will ensure that it has a full lifespan of 500+ cycles.
- 4. Empty the water from vest and hang upside-down with bladder lid open until system dry to touch.

FAILURE TO ADHERE TO WARNINGS, INCORRECT STORAGE, USAGE OR CARE METHODS, AS WELL AS USE OF INCOMPATIBLE DEVICES MAY DAMAGE THE PRODUCT AND WILL VOID FACTORY WARRANTY.

FRONT OF INSTRUCTION INSERT BACK OF INSTRUCTION INSERT